AMC 3

AASTRA

Admin User Guide for iPhone

amc-3_iphone_ug_en_2012-10

October 29, 2012

Contents

1 Welcome to Aastra . . . 5
1.1 Overview . . . 5
1.2 Fixed Mobile Convergence . . . 5
2 Introduction to the User Guide . . . 6
3 Introduction to the AMC . . . 7
3.1 Feature Overview . . . 7
3.2 How to read this Manual . . . 8
4 Restrictions . . . 9
4.1 iOS . . . 9
4.2 Ringer and Alerts for VoIP Calls . . . 9
4.3 Details . . . 10
5 Data Usage Overview . . . 12
6 Installation and AMC configuration from the AMC Portal . . . 13
6.1 Installation . . . 13
7 General Operation of the AMC . . . 14
7.1 Configure Access Points (APs) . . . 14
7.2 Home Screen Navigation . . . 15
7.3 Registration Status . . . 15
7.4 Toolbar . . . 17
7.4.1 Contacts and Corporate Phonebook . . . 17
7.4.2 Call List . . . 18
7.4.3 Features . . . 18
7.4.4 About and Settings . . . 19
8 Features of the AMC . . . 20
8.1 Placing Calls . . . 20
8.2 Accepting Calls . . . 22
8.2.1 Cellular Networks . . . 22
8.2.2 In Stand-by (VoIP) . . . 22
8.3 Emergency Calls . . . 22
8.4 Call Types . . . 24
8.4.1 Call . . . 24
8.4.2 Callback . . . 24
8.4.3 Call-through Call . . . 25
8.4.4 Direct Call (Mobile call without passing the PBX) . . . 25
8.4.5 Anonymous Call . . . 25
8.5 In-Call Features . . . 26
8.5.1 Touch Tone . . . 26
8.5.2 Hold call . . . 26
8.5.3 Enquiry/ Consultation . . . 26
8.5.4 Blind Transfer . . . 26
8.5.5 Toggle, Complete Transfer, and Conference . . . 26

8.5.6 Fast Forwarding . . . 27
8.5.7 Handover to Cellular Networks (GSM) . . . 27
8.5.8 Handover to VoIP . . . 27
8.6 Out-Of-Call Features . . . 28
8.6.1 Call Forwarding . . . 28
8.6.2 Call Pickup . . . 28
8.6.3 Call Retrieve . . . 28
8.6.4 Activate and Deactivate DnD . . . 29
8.6.5 Absence Info . . . 29
8.6.6 SIM Switch . . . 29
8.6.7 Call Voice Mail . . . 30
9 Mobile Least-Cost Routing (MLCR) . . . 31
9.1 (HTTPS) Callback . . . 31
9.2 Call Reverse . . . 32
9.3 SIM Switch . . . 32
10 IM and Presence . . . 33
10.1 Adding Contacts . . . 33
10.2 Chatting . . . 34
10.3 Parallel Chats . . . 34
10.4 Setting the Presence Status . . . 34
11 User Settings . . . 35
11.1 Roaming . . . 35
11.2 Network Mode . . . 35
11.2.1 Packet Data . . . 35
11.2.2 *GPRS Dynamic VoIP* . . . 36
11.2.3 Dual Mode Settings . . . 36
11.3 Operator Supported Dialing (OSD) . . . 37
11.3.1 OSD Status . . . 37
11.4 UI Preferences . . . 37
11.4.1 Starting Screen . . . 37
11.4.2 UC . . . 37
11.4.3 Ring Tone . . . 38
11.4.4 Vibrate . . . 38
11.5 Premium Service Numbers . . . 38
11.6 Settings (Update) . . . 38
11.7 Features . . . 38
11.8 LCR . . . 39
11.9 Factory Reset of the AMC . . . 39
11.10 Tracing . . . 40
12 Administrator Settings . . . 41
12.1 Roaming . . . 41
12.2 Network Mode . . . 41
12.2.1 Packet Data . . . 41

12.2.2 *GPRS Dynamic VoIP* . . . 42
12.2.3 Dual Mode Settings . . . 42
12.2.4 HTTP/HTTPS . . . 42
12.2.5 HTTP(S) Port . . . 43
12.2.6 Transport . . . 43
12.2.7 Codec . . . 43
12.2.8 International Prefix . . . 43
12.3 Enhanced Network Settings . . . 43
12.3.1 Jitter Buffer . . . 43
12.3.2 Anonymous Call Prefix . . . 44
12.4 Operator Supported Dialing (OSD) . . . 44
12.4.1 OSD Status . . . 44
12.4.2 Feature Access . . . 44
12.5 UI Preferences . . . 44
12.5.1 Starting Screen . . . 44
12.5.2 UC . . . 45
12.5.3 Ring Tone . . . 45
12.5.4 Vibrate . . . 45
12.6 Premium Service Numbers . . . 45
12.7 Settings (Update) . . . 45
12.8 Features . . . 46
12.9 LCR . . . 46
12.10 Call Reverse enabled . . . 46
12.10.1 Call Reverse Number . . . 46
12.10.2 Call Reverse enabled . . . 47
12.11 Factory Reset of the AMC . . . 47
12.12 FMC Numbers . . . 48
12.12.1 PBX Dialing-in Number . . . 48
12.12.2 Voice Mail Number . . . 48
12.12.3 SIM Switch Number . . . 48
12.12.4 MTC Number(s) . . . 49
12.12.5 Fast Forwarding Number . . . 49
12.13 Server Settings . . . 50
12.14 User Account . . . 50
12.14.1 Registrar and Port Settings . . . 50
12.14.2 Username and Password . . . 50
12.15 Cellular Dialing . . . 50
12.16 Tracing . . . 51
13 Manual download from the Aastra portal . . . 52

1 Welcome to Aastra

Thank you for choosing this Aastra Mobile Client product. Our product meets the strictest requirements with regard to quality and design. The following user's guide will assist you in using the Aastra Mobile Client (AMC 3) application and answer most of the questions that may arise. If you require further technical support or information about other Aastra products, please refer to our website at http://www.aastra.com. It provides additional notes and hints on the product.

1.1 Overview

The Aastra Mobile Client brings system telephony features to your mobile telephone. It takes just a few steps to install after which the Aastra Mobile Client Plus can be used immediately and conveniently without spending too much time learning it.

1.2 Fixed Mobile Convergence

Fixed Mobile Convergence (FMC) is the integration of mobile telephones into the fixed-line communications system of a company. The Aastra Mobile Client Plus software (AMC) allows you to access the Aastra communications system services from your mobile phone, enabling complete integration with the communications system as a normal extension.

- Use your mobile phone with the Aastra communications system - the familiar communications environment accompanies you around the world and is always available.
- Switch at any time from mobile telephone to system telephone - even in the middle of a call. Depending on the situation, select the mobile telephone or stationary system telephone - accessible worldwide - with the best audio quality.
- Always be accessible under one single number - free people calling you from having to keep track of several network and call numbers.

2 Introduction to the User Guide

This user's guide describes the AMC application. You will find the user's guide and other documents for your application at:
www.aastra.com or www.aastra.com/docfinder.

For more information please refer to the documentation or to your dealer's homepage. It is your responsibility to inform yourself about the scope of functions, operation and proper use of your equipment.

- Check whether you have all the user information available on your product, whether it conforms to your product's version and whether it is up to date.
- Read through the user information carefully before using the AMC.
- Store the user information within easy reach and refer to it whenever uncertainties arise in connection with the use of the application.
- If individual features differ on the Aastra communications systems, a reference is made in this user's guide.

3 Introduction to the AMC

Thank you for using the AMC for iOS-based mobile phones. The AMC is a fixed-mobile convergence (FMC) application and runs on most phones based on the iOS 5.0 - 6.0 . Fixed Mobile Convergence (FMC) is the integration of mobile phones into the fixed-line communications system of an enterprise. The AMC installed on your mobile phone behaves like this. It acts as a regular desk phone, supporting all of the important PBX features using mobile networks.

The AMC Solution utilizes existing networks, thereby avoiding additional installation costs. To start with, the existing mobile network or Wi-Fi access point can be used.

3.1 Feature Overview

Your AMC is the key to a variety of communication services like:

1. Integrated usage of cellular networks via your corporate PBX
2. Access to PBX features (Conference, Consultation etc.)
3. Voice-over-IP (VoIP) telephony via Wi-Fi or mobile data channel *
4. Automatic handovers (VoIP » cellular network, cellular network » VoIP) *
5. Mobile Least Cost Routing (HTTPS call back & Travel SIM) *
6. Corporate directory search *
7. IM and Presence *
8. Encrypted VoIP *

Furthermore, as part of our AMC Solution, your AMC offers a range of features to make use of mobile least-cost routing (LCR) which enables you to make dynamic use of the most favorable rates depending on your location and on available networks. All user relevant information regarding the above mentioned possibilities and features will be given at the appropriate points throughout this manual.

The features marked with * require a license or depend on the used provider, the available network and the configuration by the administrator.

3.2 How to read this Manual

This manual is designed to guide you step by step through the installation, configuration and usage of your AMC, providing you with useful hints and advice to facilitate the handling of your AMC. Throughout this manual we will print any terminology used in the AMC or in the main menu of your mobile phone in *italic* letters.

This manual does not describe how to operate the other functionality of your mobile phone. Please refer to the documentation of the available desktop software or the user manual of the device itself. General pieces of information will be marked with the i-icon to the left.

Information for technicians and/or administrators will be given throughout this manual. Those pieces of information will be marked with the icon to the left.

4 Restrictions

There is a major difference between iOS before version 4 and after, namely support for multitasking. This also affects the behavior of the AMC. New smart phone types/models are released every week. To avoid solution complexity and to ease management, it is recommended to implement a mobile phone policy in the company to standardize on a limited amount of phone models. A smart phone is like a computer. You have to reboot them now and then to ensure consistent behavior (the recommendation is once a day on average).

The AMC is a powerful application, and if you have all features turned on, the AMC as well as the data connections, battery life can in worst cases be 50% shorter (dependent on phone type, OS version, network and user scenarios).

Some mobile network operators does not send out their Identity in the signaling available for the AMC to present in a Network status bar. If this is the case only "Cellular Network" will be presented.

There are a handful of destination numbers which are Emergency numbers (000, 110, 112, 118, 119, 911 and 999) which together with your mobile operator's service numbers will result in pure cellular calls ("Direct calls") where the AMC should be inactive. Please make sure these are not part of your number plan.

4.1 iOS

For phone calls in a single tasking scenario this means that, if a call is received in a cellular network (non-Wi-Fi), the AMC is closed automatically and the native phone application is in the foreground. This gives fundamental differences in what is required by an external application implementation and is the reason why the AMC only supports the multitasking version of the iOS.

The AMC is able to use the multitasking capability on iOS devices (3GS or later) with iOS 5.0 - 6.0. This means that the AMC keeps running in the background even if you leave the AMC application. You can quit the AMC like any other application running on iOS with multitasking support. Please refer to the device documentation to learn how this is done. If Dual-mode usage is part of the solution, you must make sure the Wi-Fi network is "Voice ready".

4.2 Ringer and Alerts for VoIP Calls

The native iPhone setting "Ringer and Alerts" (Settings » Sounds) applies to indirectly to the AMC. If "Ringer and Alerts" is on, in-call volume, ringer volume and touch tone

volume can be modified with the volume keys (wether the AMC is in the fore- or background).

4.3 Details

- Calls cannot be accepted with the headset button (unless the AMC is in the foreground).
- Which possibilities exist to present Caller-ID information received by cellular channel are limited by the mobile platform as such.
- Whenever an unanswered cellular call is terminated, iOS does not return to the last used application. The user has to manually re-enter AMC. This can be observed for example with a SIM switch call is made, which is only placed, but never actually established, for the activation of the new SIM card.
- Muting, or changing the call volume during cellular calls always has to be done via the native menus/buttons, which means that you could have to leave the in-call screen of the AMC.
- The AMC cannot recognize the connection of a headset. Headsets have to be activated manually by using the option" Loudspeaker" in the in-call menu of the AMC.
- Bluetooth headsets could interfere with Wi-Fi systems, as both systems use 2.4 GHz frequency band contention can be an issue. Each Wi-Fi transmitter blocks out 20 of the available 79 Bluetooth channels. This is specifically valid for lower end Bluetooth headsets.
- If PIN has been activated to unlock the screen, an incoming call cannot be answered until the PIN has been entered.
- On an iPhone, incoming VoIP calls are signaled via a notification dialog if the phone is in stand-by. This local notification dialog is controlled by the system. It controls both the ringing and the vibration. It might deviate in behavior and sound from the normal ringtone. Unfortunately, the system provides only little control for configuring this behavior to your preferences, but hopefully this will change with future versions of the iPhone.
- The AMC for iPhone can perform automatic handovers from GSM to Wi-Fi. If a call is setup in a cellular network, manual handovers to Wi-Fi will not be available. Wi-Fi to cellular handovers have to be done manually. After that, a manual handover to VoIP (Wi-Fi) will be available. The handover feature on iPhone is presently on a level where a single handover during a call can be expected to work. To retain speech quality at the highest level possible, a handover is done when the connection is seen as stable.

- iPhones do not provide an API to enable the AMC to detect automatically if the phone is in a roaming state or not. Therefore, this "Roaming" state has to be manually activated in the AMC in the "About/Status" menu page to enable the required behavior when users roam outside their "home" mobile network.
- iPhone OS requires data access during a call to show the in-call services menu. A 2G-data connection does not allow data access during a call.
- As iOS also does not allow a call to be terminated directly by the AMC, a data channel is required to request the AMCC to end it.
- The establishment of a mobile-data connection when the AMC has been logged off or is activated from sleep mode, can be perceived as slow. Until the AMC is fully registered call setup time will be longer. With a non-Operator-Supported SIM, the destination number will in this case be sent over DTMF.
- Dialing numbers of contact entries from within the AMC with an appended letter ”P” and the like is not supported.
- If contact is exited in the AMC just as a call comes in, it may occur that the ring tone is replayed only once. However, the call can always be answered.
- The service *GSM Callback* is not available on iPhone.
- Caller-ID display on iPhone is supported if 1) a data channel is available, and 2) if a local phone book is stored on the device. However, contact synchronization via iCloud is not supported.

5 Data Usage Overview

The following table clarifies exactly how much data usage is required for individual services of the AMC. The settings governing the allowed usage of cellular data channels are described in 12.2.1 on page 41.

Setting	Available Services and required data volumes
Packet Data Off	0KB, no features that require Packet Data can be used.
Packet Data Minimal	Approx. 3KB per Callback attempt, 10KB for the Corporate Contacts search with a typical result set of 5-10 users.
Packet Data Local Network & *GPRS Dynamic*	30KB per hour for registrations and keepalives with MWI, but without IM/ Presence 100KB for average IM/ Presence usage per hour. 300- 500KB per hour for feature usage in calls.
VoIP over 3G	Approx. 25 **MB** per hour with iLBC and up to 78**MB** per hour with PCMU or PCMA codecs.

6 Installation and AMC configuration from the AMC Portal

Currently, the easiest way to download and install the AMC on your phone is by using the iStore.

Important Notes

Note: Make sure your mobile operator's service numbers do not conflict with the number series of your PBX.

6.1 Installation

Using the AMC portal , it is possible to deploy a download link via SMS or Email.

Follow the link and install the AMC Client like any other application on your smartphone. Please refer to your smartphone's documentation for more information.

This way of downloading enables you to centralize the download of the AMC Client for iOS. It gives every user the possibility to actively download the AMC Client or an upgraded version of the client. This is an ideal way to facilitate mass deployments.

It is mandatory that an access point is configured on your Smartphone! If this is not the case this option for the installation of your AMC Client (s) is not possible. This configuration is also important for later registrations of the AMC Client with the AMC Controller . Make sure that your device is configured for Internet access. Please consult your handset manual for information about this.

With Internet access enabled on your phone, it should now be possible to download the Client from the AppStore.

- Open the browser of your iOS phone and type in the URL of the file (alternatively open the link you received via Email or SMS)
- Select *Download* and confirm
- Your iOS phone will now execute the download, notify you of its success and, depending on the device, prompt you to reboot the phone.
- After this reboot or immediately after the download of the file your AMC iOS will be ready to use.

7 General Operation of the AMC

The AMC seeks to blend in seamlessly with the usability concepts of the platform it runs on, and tries to closely match the functionality of your smartphone's native phone application. The following chapter contains all user-relevant information for the AMC: how to navigate within the AMC, and how to use in- and out-of-call features.

7.1 Configure Access Points (APs)

An essential service of the AMC is VoIP telephony. It is therefore crucial to be connected to an access point in order to use the features of your AMC.

Please consult the documentation of your iPhone for detailed information. A short summary follows below.

- Open the Settings in your iPhone's main menu and click on Wi-Fi
- A list of available networks will be displayed below *Choose a Network...*
- Click on *Other...* to configure a (new) access point
- Then enter all necessary information for the chosen access point (picture to the right):

Figure 1: Configure access points on iOS.

7.2 Home Screen Navigation


Telekom.de 07:45 42 %
Registered
ASTRA
1
2 abc
3 def
4 ghi
5 jkl
6 mno
7 pqrs
8 tuv
9 wxyz
*
0
#
+
Dial
Contacts
History
Features
About
Status Bar: contains registration status, and icons for missed voice messages, active call forwarding rules and your presence status.
Application Bar: contains the chat icon (if this feature is in use and configured). A small red and white circle indicates missed chat messages.
Dial Field: start dialing in this part of the touch screen to make calls. You do not have the possibility to add contacts in this screen!
Tool Bar: navigate to other screens.

Figure 2: Explanation of the AMC home screen on iOS.

7.3 Registration Status

The **Status Bar** displays your current registration status. There are different icons depending on the type of registration:

This registration icon indicates that there is a VoIP-capable data connection. This data connection may be Wi-Fi or Packet Data(refer to 12.2.1 for information about *Packet Data* settings).

This icon indicates that a system registration is in progress.

The red icon appears if the system registration has failed. This may be caused by faulty user credentials. Please contact support if this problem persists.

You will see this icon if there is currently no data connection available, and therefore no system registration possible. Whenever a configured Access Point becomes available, the AMC can re-registers itself in the system if it is configured to do so. Please note that system registration (data access) is needed for fast mode call setup method.

Registrations in Data Networks other than Wi-Fi

Please note that certain settings have to be enabled for the AMC to register over Packet Data (refer to 12.2.1).

Static Roaming

When the AMC is turned off, calls will only be routed to the *GSM Number* of a user if *Static Roaming* is activated for this user. If *Static Roaming* is deactivated on the AMCC, the AMC will not be available in cellular-only networks.

7.4 Toolbar

The toolbar of the AMC for iOS contains the following screens.

7.4.1 Contacts and Corporate Phonebook

There are some differences between this contact screen and the native contact screen. The AMC also has some additional services, for example access to your *Corporate Contacts*.

Note: This is an optional feature and will only be visible if access on the AMCC side has been enabled, and your device has data connectivity.



The *Contacts* view offers the possibility to search your local phonebook or your Corporate Contacts (in many cases an Active Directory server, data channel required!) or both at the same time by using the filter options "Contacs", "Corp. Contacts" and "All Contacts" in the top menu bar.
Enter at least two letters of the beginning of a name. The AMC will search your *Corporate Contacts* and display the found results after a couple of seconds.

Search Corporate Contacts

Type in at least two letters into the search field and press the icon to start the search. Upon a search request, the AMCC will only forward the first 25 results to the AMC. If that list does not contain the contact you are looking for, provide a more specific request.

Example: If entering the first four letters returns more than 25 items - and the one you are looking for is missing - enter the first 5 or 6 letters to further specify your search.

Avatar Pictures

Note that avatar pictures of your Contacts are only shown for inbound and outbound calls if the contacts have been loaded at least once. Contacts are loaded as soon as you open the Contacts screen in the AMC. They have to be reloaded after a restart. Later versions of the AMC also offer a Refresh button at the bottom of the screen (highlighted in the screenshot above).

7.4.2 Call List



The *Call List* screen is similar to the *Recents* screen in the native menu of your phone. However, as you can see in the picture to the left, there are some differences:

- Your AMC categorizes calls as *Dialed*, *Answered* and *Missed*.
- The *Call List* view only shows calls *Dialed*, *Answered* and *Missed* via the AMC, not the calls made via the native dialer.
- Touching the entry initiates an automatic callback to the entry's phone number.
- The arrow on the right hand side of each call log entry opens the details view where you can initiate a *Call Type* (refer to 8.4).

7.4.3 Features

How to operate the out-call features located on this screen is explained in section 8.6.

7.4.4 About and Settings

The last screen that is directly accessible from the home screen shows some information *About* your AMC.

Press ”Settings” in the page title to open the settings view (refer to section 11).



Figure 3: *About* and *Settings* page on iOS.

8 Features of the AMC

The following explains all call related services of your AMC.

General Availability of Features

Available in- and out-call features depend on your PBX; for some features please consult your PBX documentation. More or less features than the ones described below might be available in your specific case. Features displayed by the AMC can be configured through the feature file and can hence even vary on a per-user basis. The Feature file is downloaded when you start your AMC the first time. It can also be downloaded manually. There can be several feature files available but only one is assigned per user.

Contacts Sorting

Sorting in the AMC is always done by Family name. This is not configurable as might be the case in the native Contacts. The reason is that access to this capability can differ widely.

8.1 Placing Calls

To place a call using the AMC, type a number into the dial field and press the green phone button. You can also dial from the *Contacts* screen (refer to 7.4.1) or *Call List* screen (7.4.2).

As soon as a call has been established, in-call features (refer to 8.5) will become available. If a Wi-Fi or Packet Data connection is available the AMCC will give feedback about the status of the call(s). This feedback will be displayed in the in-call screen.

Call Quality

The AMC displays the current "Call Quality" (voice quality) in a bar in the home screen during a call. Please note that for pure cellular calls, the quality will always be at 100%, because measuring values for the calculation of the call quality are not possible.

Redial

A double touch of the green phone button will redial the last dialed number.

Call Setup Time

The call setup time when using the AMC is slightly longer than when using the native application, because the call is set up via the call manager (AMCC) in the enterprise network. If the AMC is registered over the cellular network the call setup time is usually less then 10 seconds. If the phone does not have access to data the call setup is done via DTMF which usual takes approx. 10-20 seconds.

Note: It is advisable to disable the call-waiting function of the native dialer, since this might lead to confusion of the call legs (you would have to switch from the native application to the AMC and back in certain situations).

8.2 Accepting Calls

8.2.1 Cellular Networks

Due to properties of iOS the AMC is put to the background if there is an inbound call from cellular networks. However, as soon as the call is picked up and established, and if "Apple Push Notifications" are activated on the AMCC (*Global Settings*) a pop-up will ask you if the AMC should be started. The AMC will automatically register itself on the AMCC if a data channel is available and in-call features will consequently become available.

The Apple Push Notification (APN) is a service offered by Apple. In the *System Status* tab of the AMCC you can verify if the service is currently available.

8.2.2 In Stand-by (VoIP)

If the iPhone is in stand-by while an AMC (VoIP) call comes in, unlocking it with the slider means accepting the call. This behavior is the same, whether or not the AMC is in the background. In VoIP there is also a pop-up informing you about the caller's ID (this is done via local push).

Caller ID

The AMC for iOS supports the transmission of Caller IDs ("see who's calling") via the AMCC. To make use of this possibility, and to not be subject to different policies regarding the transmission of Caller IDs of the different providers, the following settings have to be applied:

1. The contact data must be available locally, i.e. on the device. Contact synchronization via iCloud is not supported.
2. Packet Data has to be set to *GPRS Dynamic* or *Local Network*; refer to 12.2.1.
3. The *MTC Number* has to be set on the AMC if the operator does not include the original Caller ID in the signaling. For the Caller ID transmission to work properly the *MTC Number* has to match 100%, a matching prefix is not enough; refer to 12.12.4.

8.3 Emergency Calls

Emergency calls have to be placed as direct calls, i.e. not with the AMC.

This is done automatically for the major emergency numbers such as 112 and 911. Local emergency numbers that have to be dialed directly can be specified as Exception Numbers. Refer to 12.6 on page 45.

8.4 Call Types

There are several call types that you can select before dialing. They give you manual access to the potentially cost saving features of the AMC. Please see the picture below.

Automatic Routing

Administrators may specify and deploy routing rules (for Callback etc.) with in an (M)LCR Table and deploy it to the AMC.

Note: Which of the following call types are available and/or how they are routed (VoIP/-cellular) depends your AMC's settings and on your registration status. For example: Callback will not be offered if you are registrered for VoIP, because there is no advantage in using it.



Figure 4: Enter a number and hold the phone button to select one of the available call types.

8.4.1 Call

This is either a VoIP call (if the needed registration is available), or a Call-Through call for cellular connections.

8.4.2 Callback

Demand a Callback and let yourself be connected with the called party. No call will be established from your smartphone. This may have a favorable effect on costs. A Callback is requested via HTTPS.

To use the *HTTPS Callback*, the *HTTPS Port* must be set (refer to 12.2.5). Generally the call type selection panel will be presented when the user holds one of the items below, somewhat longer than just touching it:

- the call button in the dial screen
- a contact to setup a call
- an entry in the call list.

8.4.3 Call-through Call

If there is no registration or if the AMC is only registered for signaling (blue registration icon), you will have the option to select a call-through call to ensure that your call is routed through the system. Otherwise, i.d. if you are registered for VoIP (green icon) this call type will not be offered.

8.4.4 Direct Call (Mobile call without passing the PBX)

This option gives you the possibility to place a call "directly" through the mobile network. Such a call will then not be routed through your enterprise network.

8.4.5 Anonymous Call

When you select an *Anonymous Call* the called party will not see your caller ID. Unlike *Direct Call*, this feature has to be routed through your enterprise network.

Further Configuration

1. This is a PBX-driven feature. Not every PBX supports this.
2. The Anonymous Call Prefix has to be set in the *Settings* of your AMC, refer to 12.3.2.
3. An Access Code has to be configured on the AMCC to match the feature code that triggers an *Anonymous Call* on your PBX (please refer to the Aastra Mobile Client Controller Administrator Manual).

8.5 In-Call Features

If a data channel (Wi-Fi or *Packet Data*) is available during a call, your AMC will enable the in-call features of your PBX. For example: The in call menu will not be available during a 2G call as no data access is possible during call (if no Wi-Fi is available for signaling).



8.5.1 Touch Tone

A click on this option opens a screen to send DTMF (Dual Tone Multi Frequency). This can be used to enter a conference room where a "password" in the form of tone signals has to be used.

8.5.2 Hold call

A party can be put on hold by clicking the *Hold* option on the screen. You can resume the call at any time.

8.5.3 Enquiry/ Consultation

Clicking on this option[a] in the in-call features screen puts the currently active call on hold and opens the call screen where you can call a second party. A reconnect tone will be played back if the Enquiry fails (called party unavailable).

[a] The name of this feature differs depending on the used Aastra Enterprise Communications PBX.It is either "Enquiry" or "Consultation".

8.5.4 Blind Transfer

Transfer a call to a second party. Select this feature and choose a contact or select a number. Your call will be terminated and disappear from the home screen as soon as the other party has picked up.

8.5.5 Toggle, Complete Transfer, and Conference

If there are two active calls (one of them on *Hold*), you can *Toggle* back and forth between them, enter a three-party conference (*Complete conference*), or join the two calls (*Complete transfer*) and terminate the calls on your end.

8.5.6 Fast Forwarding

This option will forward the call to a predefined number. While in theory this can be any number, this feature is most often used to transfer the call to the desk phone with a single touch of a button. While the transfer to the predefined number is being executed, the AMC offers you the possibility to *Resume* the call (the transfer will be interrupted).

Please note that this feature is executed like a Blind Transfer. If your PBX does not support Blind Transfers, the Fast Forwarding feature will not be available.

For immediate transfer a *Fast Forwarding Number* has to be set (refer to 12.12.5). If no *Fast Forwarding Number* has been set, the AMC will open a keypad with which you can dial or choose a contact.

8.5.7 Handover to Cellular Networks (GSM)

Select the icon to trigger a manual Handover to GSM (cellular networks). You can find it in the second screen of the in-call features.[1] The handover is done through a request towards the AMCC – resulting in an incoming call in the background, that has to be answered.

8.5.8 Handover to VoIP

The AMC supports automatic handovers from cellular networks to VoIP from version 1.3 on. This however, can only be done by manually bringing the AMC to the front during an ongoing cellular call, because the AMC is pushed to the background whenever a cellular call comes in.[2] If there is a VoIP access point available at that time, the AMC will automatically hand over this call.

If the access point provides a VoIP over 3G (*Packet Data* set to *Full Dynamic*), it will not be possible to get back to a Wi-Fi access point during the call. This depends on that the phone can only have one single IP-address.

At the availability of a network with sufficient quality, the AMC will take some time to assure it is a stable connection before a handover is performed.

[1] Due to platform properties, this feature will force the AMC to close. However, you will receive an incoming call which will reconnect you to the second party.

[2] This is also due to platform properties. The iPhone operating system grants priority to incoming cellular calls over any third-party application.

8.6 Out-Of-Call Features

Out-of-call features give you the possibility to use your smartphone as a full-fledged equivalent of a desk phone. You can access the *Features* screen via the tool bar navigation in the home screen of the AMC.

8.6.1 Call Forwarding

You have the option to configure rules about when and to which destination *Call Forwarding* is to be done. There are three different rules: *Always*, *On no Reply* and on *Busy*. A different number may be configured for each of them.

Rules can be cancelled globally with *Cancel call forwarding* or switched on and off with *Toggle On/Off*.

If a call has been forwarded to your AMC, this will be indicated by a diversion arrow in front of the caller's number.

8.6.2 Call Pickup

A pick-up group is a group of people who are notified if one group member receives a call, for example a support group. If there is an inbound call for your pick-up group, the AMC will notify you with a pop-up window and give you the option to pick up the call. Clicking on *Call Pickup* in the *Features* screen also enables you to pick up the first incoming call for your pick-up group.

Pickup Groups

There might also be adjustments to be made on the AMCC and PBX-side. Please consult the Aastra Mobile Client Controller Administrator Manual (keywords: *PBX Access Codes*, *Pickup Groups*).

8.6.3 Call Retrieve

This out-call feature enables you to fetch a call from the waiting loop. If this does not work as expected, please verify that your PBX supports this feature, and contact support if the problem persists.

8.6.4 Activate and Deactivate DnD

Temporarily disable your AMC as your corporate extension with Do-not-Disturb (DnD). This prevents inbound calls from being forwarded to your AMC (VoIP and cellular). *Deactivate DnD* to be available for inbound calls again.

8.6.5 Absence Info

By selecting the Absence Info menu you can set the absence reason and in some cases the day/time of return, in your PBX as well as cancelling already set information.

8.6.6 SIM Switch

This is a least-cost routing feature explained on page 48.

Use this option to activate a new SIM card (the number must be assigned to your user account in the system).

If Automatic Start is activated, and if the SIM card requires PIN activation, the AMC won't detect the new SIM card until a AMC was restarted.

8.6.7 Call Voice Mail

Listen to your corporate voice mail with this option. Click on the line *Call Voice Mail* in the *Features* screen to start the call.



A waiting voice message will be indicated by a small cassette icon on the right side of the top bar in the Dial screen. Once you have listened and deleted your received voice mail(s) this icon will disappear.

9 Mobile Least-Cost Routing (MLCR)

The following explains how to actively use the features *Callback*, *Call through*, and *SIM Switch*.

Roaming

iOS does not provide information to the AMC application if the phone is roaming or not roaming. Therefore, the user has to change this manually. Go to the About/Status screen and change the roaming status when traveling internationally.

About MLCR

It is possible to configure number patterns (first couple of digits of a phone number) which will trigger an automatic least-cost routing. These 'routing rules' can be deployed to the AMC from the Aastra administration portal by the Administrator. The Administrator can configure several different MLCR lists in the Portal to customize the MLCR rules for each user if necessary.However, a different routing feature can be selected manually by the user even if these routing rules are present, refer to 8.4.

9.1 (HTTPS) Callback

Use Callback to reduce costs of outbound calls made via the AMC. In a Callback call the call to both the A- and B-party are setup from the PBX. How to start a *Callback* is explained in 8.4 on page 24. If your company makes global use of the MLCR, dialing certain phone numbers might trigger a *Callback* automatically! Rules for automatic routing can be made and deployed to the AMCs using the AMCC.

Note: The HTTPS Callback request goes through a data connection that might not be available or fail. In the case of failure, the AMC will automatically fall back to a Call-through call. The call is still placed through the PBX, however, you do not have the cost benefits anymore.

A Callback is invoked via HTTPS . The AMC also sends the phone number that you would actually like to call (1). The AMCC in return calls the AMC (2) and the destination number (3). The two calls are connected as soon as they are established.

Further Configuration: HTTPS Callback

HTTPS is enabled automatically on the AMCC. On the AMCs the use of packet data (refer to 12.2.1) has to be allowed.



Figure 5: Simplified functionality of Callback.

9.2 Call Reverse

If *Call Reverse* is enabled, inbound calls (to the users mobile number) can be transformed into outgoing calls to make use of favorable tariffs for calls from the cellular network. This happens automatically, so from the user perspective a *Call Reverse* completely resembles an inbound call: you can decline or accept it.

Requirements

This service requires a data channel!.
General setup and functionality are explained in section 12.10.1 on page 46.

9.3 SIM Switch

The SIM Switch feature can also help save calling costs. Especially when using local SIM cards abroad. As an out-call feature, the usage of this feature is explained in 12.12.3 on page 48.

10 IM and Presence

The AMC enables basic mobile presence and the ability to chat with your smartphone. Immediately after the required settings have been configured (see infobox below), the Online/Offline Presence Status will be displayed in the Home screen.



Figure 6: Overview of IM and presence icons and options.

Required Settings

UC has to be turned *On* (refer to 12.5) , and profiles of *XMPP Endpoints* and *XMPP User Accounts* or *SIMPLE User Accounts* have to be created on the AMCC.

10.1 Adding Contacts

The AMC for iOS adds contacts automatically to the chat roster if an Instant Messaging ID is found in the contact entry:

- To add a contact open the native *Contacts* directory, open a contact and click *Edit*.
- Click on *Add field*, then click on the setting *Instant Message*. Enter the ID of the user, tap the default "AIM" setting, select "Jabber" as protocol/way of chatting - and save your changes.

Note: Please make sure that entered email addresses pass a validity test, i.e. they have to constist of the following: [name]@[domain].[xx]!

Most XMPP servers are case sensitive! Please make sure that email addresses are entered exactly as they are configured on the XMPP server. If this is not the case, Presence subscriptions will most likely fail!

Limitation

Please note that once added to the IM roster, a contact cannot be deleted, blocked or ignored. An option to delete IM contacts will be implemented in a later version of the AMC.



10.2 Chatting

To start a chat, touch the speech-bubble icon in the Dial screen again Client. Then touch the option *Start Chat*. You have then the option to enter a chat ID manually, or to choose one of your contacts. Once the *Chat* screen is open (see screenshot to the left), simply type in a message and click return to send your message.

10.3 Parallel Chats

It is also possible have several conversations at the same time. All ongoing chats will be displayed as a list in the Chat screen.

10.4 Setting the Presence Status

By default your first presence status will be *Offline*. To change this, touch the speech-bubble icon in the Dial screen of your AMC. Touch the option *Set presence* in the following screen. In the screen shot to the left Online and Offline are the supported Presence States. Simply select the one you would like to apply.

Do not Disturb: This presence state is set automatically if there is an ongoing call. It will return to the previously set presence status after the call has been terminated.

11 User Settings

There are a couple of mandatory settings that have to be configured to be able to use all of your AMC's features. All settings, mandatory and optional, are explained in this chapter.

Configuration Loss with Firmware Updates

With a firmware update, the AMC application will not be deleted. However, the configuration of your AMC will be lost and must be reloaded. To download the configuration data manually, open the *Settings* section of your AMC, and re-enter the Registrar, Username and Password settings.

If the *Hide settings* checkbox has been set by the Admin in the AMC Portal, some of them might not be visible to the user.

Never change preconfigured Settings!

Every number has to be configured on the AMCC, and will hence in most cases be preconfigured on the AMC. If one of them does not work properly, ask your administrator to check if the according feature has been activated for your User Account on the AMCC. If your AMC has been preconfigured, simply skip the Configuration chapter. However, you may want to consult it, to fully understand how your AMC works. The AMC downloads the configuration from the Aastra portal.

11.1 Roaming

Currently the *Roaming* status has to be set manually, because this information cannot be retrieved on iOS. If a user is abroad or making calls from any other than his home cellular network, this status should be adjusted. This ensures that call-routing is done as desired, i.e. as it is configured in the *LCR Settings*.

Note: This might change with later releases of iOS.

11.2 Network Mode

11.2.1 Packet Data

Unlike Wi-Fi connections, cellular connections cannot carry data. Availability of data channels depends on your provider and on your contract. Many contracts come with a certain amount of data traffic included *Packet Data*.

The Packet Data settings described here allow you to determine if and how the AMC is allowed to use cellular *Packet Data*. You can choose to generally disable it for the AMC (*Off*), use it exclusively for HTTP(S) requests (*Minimal*, i.e. Corporate Contacts access, *HTTPS Callbacks* etc.), or allow its usage only in your provider's network (*Local Network*). To use it whenever needed for a system registration (no Voice over 3G) set this to *GPRS Dynamic*.

Local Network + Roaming = _Minimal_

Please note that while in roaming in other provider networks and while the setting *Local Network* is active, the actual usage of the cellular data channel is done according to the setting *Minimal*, i.e. registrations are not possible and only HTTP(S) requests are allowed.

11.2.2 *GPRS Dynamic VoIP*

To allow general usage and Voice over 3G use *GPRS Dynamic VoIP*.

Native Settings Dependent

Smartphones have preference options to enable or disable the use of packet data. If turned off in the native menu, any preferences made within the AMC remain without effect!

Costs and Battery Life

Please note that the usage of data channels, especially with Voice over 3G (*GPRS Dynamic VoIP*), may drain the phone's battery. If costs run too high, a provider might also disconnect the call. Section 5 on page 12 contains information about the amount of data consumed by certain features.

11.2.3 Dual Mode Settings

Select *Single Mode* or *Dual Mode*:

In *Single Mode* it allows cellular networks and Packet Data for signaling (*Packet Data* and/or Wi-Fi, this depends on the device), i.e., if you want to have SIP signaling over Wi-Fi but call-setup signaling and media over the cellular network, you need to select the *Single Mode* setting!

The setting *Dual Mode* allows Voice-over-Wi-Fi, but it requires that the iOS device supports Wi-Fi and that the required settings in the native OS are made.

Consumption of Packet Data

The *Packet Data* setting lets you specify when packet data (for example *Packet Data*) should be used; refer to 12.2.1.

Native-Dialer Dependent

Whether a data channel is established via Wi-Fi or via *Packet Data* depends on the Network Preferences you have chosen in the native iOS application. If a preferred Wi-Fi network is available, this network will be used for the data channel.

11.3 Operator Supported Dialing (OSD)

Some operators can call your configured *PBX Dialing-in* number automatically. Please note that this will only work with the SIM card for which your AMC was activated. If your provider supports OSD and if you would like to use it, set this setting to *On*.

11.3.1 OSD Status

Turn OSD on or off by changing the OSD Status. This will only be applied when you are not in a *Roaming* (refer to 12.1) state.

11.4 UI Preferences

The following settings let you personalize your AMC.

11.4.1 Starting Screen

As mentioned earlier, there are two possible Starting screens to choose from for your AMC; the *Dialer* and the *Contacts* screen.

11.4.2 UC

Set this to on to enable the use of instant messaging (IM) and presence. Check the IM and Presence chapter 10 to learn more about this functionality.

11.4.3 Ring Tone

Specify the ring tone that your AMC shall use. The setting *Default Ringtone* is an AMC specific ring tone.

11.4.4 Vibrate

This gives you the possibility to switch vibration on or off for calls handled by the AMC. In Wi-Fi mode only one single alert or vibration (for ∼10 secs) will take place at an incoming call with the AMC in the background.

11.5 Premium Service Numbers

Specify numbers that must be dialed directly in all cases. The main purpose is to make sure that special numbers such as operator voice mail and the like are not considered for any special routing via the AMC.

To specify more than one number, separate them with dashes "-" (no white spaces).

Note: Emergency numbers do not have to be specified here, as they are treated separately. The major emergency numbers for all continents such as 112 and 911 are preloaded in the AMC. If you have any special or regional numbers however, you can configure them here.

11.6 Settings (Update)

With these settings you can:

- Set your preference for configuration updates (automatic On/Off)
- Check the date of the last configuration update update. There will be an automatic update when the AMC first registers, so there will be a date here, even if you haven't triggered a manual download yet.
- Update Settings: with this option, all settings available on the AMCC will be updated.

11.7 Features

Tap "Feature File Download" to download the latest feature file from the AMCC (in- and out-call feature codes).

11.8 LCR

With these settings you can:

- Set your preference for using least-cost routing rules (automatic routing On/Off)
- Check the date of the last configuration LCR update. There will be an automatic update when the AMC first registers, so there will be a date here, even if you haven't triggered a manual download yet.
- Update LCR: with this option, LCR rules will be updated.

11.9 Factory Reset of the AMC

It is possible to do a quick, but complete factory reset. Open the *About* screen, and click on *Status* (top navigation), scroll down to the options *Factory Reset/Local Data* and *Factory Reset/Local Data and Settings*. *Local Data* only resets the parameters that can be entered within the AMC (*Status* page), *Local Data and Settings* also resets the parameters saved in the *Settings/AMC* interface.

11.10 Tracing

A support trace can be initiated on the *Status* page just like a factory reset. Please note that users should only use the trace service if asked to do so by their system administrator.

Figure 7: Open the *Trace Type* screen.

Depending on the issue that is observed with the AMC, the *Trace Type* should be narrowed down to:

- **Audio:** If the voice quality seems insufficient etc.
- **Call Setup:** Problems occur when a call is initiated.
- **Crash:** The AMC shuts down unexpectedly.
- **Network:** For registration issues etc.

The collected traces can then be forwarded by email.

Simple Logging

If there are issues with the Caller ID, use the option "Simple Logging". All logs regarding Caller ID transmission will then be saved to the file `iPhone_simple_log.txt`.

12 Administrator Settings

Tap the title bar ("Settings") three times to open a prompt to enter the passphrase for access to the administrator settings. Passphrases change over time (every day/24h), and can be retrieved from our support team. These settings are blocked from user modification to ensure aptness of settings.

Administrators: Use the AMC Portal to configure settings remotely!

12.1 Roaming

Currently the *Roaming* status has to be set manually, because this information cannot be retrieved on iOS. If a user is abroad or making calls from any other than his home cellular network, this status should be adjusted. This ensures that call-routing is done as desired, i.e. as it is configured in the *LCR Settings*.

Note: This might change with later releases of iOS.

12.2 Network Mode

12.2.1 Packet Data

Unlike Wi-Fi connections, cellular connections cannot carry data. Availability of data channels depends on your provider and on your contract. Many contracts come with a certain amount of data traffic included *Packet Data*.

The Packet Data settings described here allow you to determine if and how the AMC is allowed to use cellular *Packet Data*. You can choose to generally disable it for the AMC (*Off*), use it exclusively for HTTP(S) requests (*Minimal*, i.e. Corporate Contacts access, *HTTPS Callbacks* etc.), or allow its usage only in your provider's network (*Local Network*). To use it whenever needed for a system registration (no Voice over 3G) set this to *GPRS Dynamic*.

Local Network* + Roaming = *Minimal

Please note that while in roaming in other provider networks and while the setting *Local Network* is active, the actual usage of the cellular data channel is done according to the setting *Minimal*, i.e. registrations are not possible and only HTTP(S) requests are allowed.

12.2.2 *GPRS Dynamic VoIP*

To allow general usage and Voice over 3G use *GPRS Dynamic VoIP*.

Native Settings Dependent

Smartphones have preference options to enable or disable the use of packet data. If turned off in the native menu, any preferences made within the AMC remain without effect!

Costs and Battery Life

Please note that the usage of data channels, especially with Voice over 3G (*GPRS Dynamic VoIP*), may drain the phone's battery. If costs run too high, a provider might also disconnect the call. Section 5 on page 12 contains information about the amount of data consumed by certain features.

12.2.3 Dual Mode Settings

Select *Single Mode* or *Dual Mode*:

In *Single Mode* it allows cellular networks and Packet Data for signaling (*Packet Data* and/or Wi-Fi, this depends on the device), i.e., if you want to have SIP signaling over Wi-Fi but call-setup signaling and media over the cellular network, you need to select the *Single Mode* setting!

The setting *Dual Mode* allows Voice-over-Wi-Fi, but it requires that the iOS device supports Wi-Fi and that the required settings in the native OS are made.

Consumption of Packet Data

The *Packet Data* setting lets you specify when packet data (for example *Packet Data*) should be used; refer to 12.2.1.

Native-Dialer Dependent

Whether a data channel is established via Wi-Fi or via *Packet Data* depends on the Network Preferences you have chosen in the native iOS application. If a preferred Wi-Fi network is available, this network will be used for the data channel.

12.2.4 HTTP/HTTPS

Choose HTTP or HTTPS. The port on the AMCs (12.2.5) and the AMCC has to be set accordingly if non-default ports are to be used.

12.2.5 HTTP(S) Port

If a port is configured here and if HTTP(S) has been activated on your AMCC, data connections will be established automatically whenever necessary(for Callbacks, to access the Corporate Contacts etc.).

12.2.6 Transport

The AMC supports the following transport protocols: TCP and TLS. If TLS is used, the AMC will negotiate certificates with the AMCC. The (manual) installation of a certificate is not necessary. The default setting is TCP .

12.2.7 Codec

These settings should not be altered. The factory default values of the AMC are normally apt to a variety of network configurations. There should hence be no need for modification.

The AMC for iPhone supports U-law, A-law and iLBC.

12.2.8 International Prefix

In this field you can specify with which characters a leading plus "+" should be replaced whenever it is signaled in DTMF.

12.3 Enhanced Network Settings

The first two settings here should not be altered. The third setting enables the call type (refer to 8.4) *Anonymous Call Call*.

12.3.1 Jitter Buffer

This setting should not be altered. The factory default values of the AMC are normally apt to a variety of network configurations. There should hence be no need for modification.

12.3.2 Anonymous Call Prefix

If your PBX supports outbound anonymous calls (no caller ID shown) enter the necessary feature code here. The option *Anonymous Call* will become available whenever you enter or select a phone number and open the call options menu by touching and holding the phone button, an entry in the contacts or call log screen.

This has to be configured as a *PBX Access Code* on the AMCC!

12.4 Operator Supported Dialing (OSD)

Some operators can call your configured *PBX Dialing-in* number automatically. Please note that this will only work with the SIM card for which your AMC was activated. If your provider supports OSD and if you would like to use it, set this setting to *On*.

12.4.1 OSD Status

Turn OSD on or off by changing the OSD Status. This will only be applied when you are not in a *Roaming* (refer to 12.1) state.

12.4.2 Feature Access

Note: This setting is only needed if Operator Supported Dialing (OSD) is used! Refer to 12.4.

Enter a number here that makes your PBX route a call to the AMCC. This number will then be dialed to ensure the functionality of out-call features such as Call Forwarding in conjunction with OSD.

12.5 UI Preferences

The following settings let you personalize your AMC.

12.5.1 Starting Screen

As mentioned earlier, there are two possible Starting screens to choose from for your AMC; the *Dialer* and the *Contacts* screen.

12.5.2 UC

Set this to on to enable the use of instant messaging (IM) and presence. Check the IM and Presence chapter 10 to learn more about this functionality.

12.5.3 Ring Tone

Specify the ring tone that your AMC shall use. The setting *Default Ringtone* is an AMC specific ring tone.

12.5.4 Vibrate

This gives you the possibility to switch vibration on or off for calls handled by the AMC. In Wi-Fi mode only one single alert or vibration (for ∼10 secs) will take place at an incoming call with the AMC in the background.

12.6 Premium Service Numbers

Specify numbers that must be dialed directly in all cases. The main purpose is to make sure that special numbers such as operator voice mail and the like are not considered for any special routing via the AMC.

To specify more than one number, separate them with dashes "-" (no white spaces).

Note: Emergency numbers do not have to be specified here, as they are treated separately. The major emergency numbers for all continents such as 112 and 911 are preloaded in the AMC. If you have any special or regional numbers however, you can configure them here.

12.7 Settings (Update)

With these settings you can:

- Set your preference for configuration updates (automatic On/Off)
- As an administrator (passphrase must be entered to access administrator settings, refer to 12) you also have the option to enter the OTA-URL here (check the longer description in the next section).
- Check the date of the last configuration update update. There will be an automatic update when the AMC first registers, so there will be a date here, even if you haven't triggered a manual download yet.

- Update Settings: with this option, all settings available on the AMCC will be updated.

OTA-URL

The OTA-URL is the link to the Aastra administration portal, from where the AMC will download the configuration (including license), Feature file and LCR file.

12.8 Features

Tap "Feature File Download" to download the latest feature file from the AMCC (in- and out-call feature codes).

12.9 LCR

With these settings you can:

- Set your preference for using least-cost routing rules (automatic routing On/Off)
- Check the date of the last configuration LCR update. There will be an automatic update when the AMC first registers, so there will be a date here, even if you haven't triggered a manual download yet.
- Update LCR: with this option, LCR rules will be updated.

12.10 Call Reverse enabled

12.10.1 Call Reverse Number

The *Call Reverse Number* is only mandatory if the feature is to be used. It has to be a number, again in international format, that has been configured for the *Call Reverse* purpose on the AMCC.

This can be enabled and disabled globally; refer to 12.10.2.

How it works

The calling party will basically be put on hold by the AMCC; as a consequence a *Call Reverse* from the calling party's perspective is no different from a normal call. The AMCC will even play back a ring-back tone.

Only inbound calls coming from the AMCC are affected by this! Regular inbound calls to your SIM card remain untouched.

Advantages of Call Reverse

Call Reverse turns inbound calls into outbound calls and thus reduces cost, especially in Europe and other countries with high termination charges. Through these charges calls from fixed line to mobile are expensive whereas calls from mobile to fixed line are typically cheap.

12.10.2 Call Reverse enabled

If this option is enabled inbound calls will be rejected and an automatic call back to the party in concern is initiated. Refer to 12.10.1 for a description of *Call Reverse*. The option *Maintain 3G Connection* is automatically enabled if *Call Reverse* is enabled.

12.11 Factory Reset of the AMC

It is possible to do a quick, but complete factory reset. Open the *About* screen, and click on *Status* (top navigation), scroll down to the options *Factory Reset/Local Data* and *Factory Reset/Local Data and Settings*. *Local Data* only resets the parameters that can be entered within the AMC (*Status* page), *Local Data and Settings* also resets the parameters saved in the *Settings/AMC* interface.

12.12 FMC Numbers

In order to take advantage of the available AMC Solution features the AMC and the AMCC "communicate" via special numbers which must be configured on the AMCC to trigger a certain behavior in cellular networks.

12.12.1 PBX Dialing-in Number

The *PBX Dialing-in Number* is used for cellular calls. It is used by the AMC to route the calls through your company network (AMCC). It makes extension dialing from the AMC possible i.e. (calling colleagues via their extensions numbers and not their full numbers). It also ensures that your corporate phone number is displayed to the called party and not the number of your currently used SIM card.

AMCC-Side

This number has to be configured for the *PBX Dialing-in* purpose on the AMCC!

E.164 Format

The *PBX Dialing-in Number* has to be configured in E.164 format to ensure that the AMC is always able to dial it independently from its location.

12.12.2 Voice Mail Number

If your Voice Mail is configured here, you have the possibility to access your corporate voice mail messages via the AMC.

12.12.3 SIM Switch Number

If you select *Activate SIM Card* in the main menu, the AMC uses this number to communicate to the AMCC that a new SIM card has been inserted. If the number of this SIM card is configured for your *User Account* on the AMCC, your new SIM card will be activated and you will be able to take advantage of the features of the AMC Solution.

Advantage of SIM Switch

All of the services offered by the AMC are exclusively available for configured users. However, some users might have several SIM cards, mostly for taking advantage of lower tariffs in different countries. It is possible to configure up to ten cell phone (SIM card) numbers per user, but only one at a time will be "active".

How it works

A call to *SIM Switch* number is placed and hung up immediately. This guarantees that the call is free of charge since it is never really established. If the SIM Switch request was unsuccessful, you will not be able to make calls from now on, since the AMCC cannot authenticate you. Such a failure should not happen, unless your new SIM number was configured incorrectly on the AMCC.

What to do if SIM Switch doesn't work

If Automatic Start is activated, and if the SIM card requires PIN activation, the AMC won't detect the new SIM card until a AMC was restart. Restart the AMC to see if the problem persists.
Your previously used SIM card will continue to work, unless there is a problem on the AMCC-side: Check if there is a temporary problem by reinserting the former SIM card. If it does not work, the error is likely to be located at the AMCC.
If repeated attempts to Activate SIM Cards fail and if the configured number of the second SIM card is correct, the reason could be an improper Caller ID sent from your new SIM card. In those cases the switch has to be conducted manually on the AMCC.

12.12.4 MTC Number(s)

MTC stands for Mobile Terminated Call. The *MTC Number* will be associated as Caller ID for your corporate system (AMCC). You could say that this is the identification the AMCC uses towards the AMC. If the *MTC Number* is set, all Enterprise calls must come with this Caller ID otherwise they will not be handled by the AMC. In order to make sure that the number is positively matched, you have to enter your PBX number in international format.

Use Case

The *MTC Number* or prefix identifies a call as an Enterprise (AMC) Call. All AMC Solution features become available for identified *Enterprise Calls*. A 100% match of the *MTC Number* is required for the transmission of Caller IDs (refer to 8.2.2).

Note: To be able to present some Caller ID information when an operator uses CLIP-call screening, the AMC introduces an entry in the Contacts if an MTC number is set in the client configuration.

12.12.5 Fast Forwarding Number

Configure the phone number for the phone you want to have as Fast Forwarding destination In most cases this will be your desk-phone number, but it can be any number.

The AMC will offer the option *Fast Forwarding* in the in-call features menu. This option can be used to transfer an active call instantly to the pre-configured number.

12.13 Server Settings

The IP address is the IP address or host name of your AMCC (or the first network device in between AMC and AMCC). The default port is 5062.

12.14 User Account

12.14.1 Registrar and Port Settings

The IP address and port that have to be entered here, as well as your user credentials, should be given to you by your system administrator.

12.14.2 Username and Password

The *Username* is the username that has been registered on the AMCC. Usually it is your corporate phone number (to make it unique in the system). The *Password* is the one that belongs to your username in the AMCC.

12.15 Cellular Dialing

The *Maximum Number Length* determines after how many digits (of a phone number) the AMC will send DTMF (in cellular networks). In most cases, this depends on the first network device on the way (gateways and trunks in many countries support up to 19 sometimes even 21 digits). To ensure the correct functionality, simply set this value to "0".

Attention

This setting can be used to expedite the dialing of Call-through calls, basically getting it to the same level as with operator supported dialing (OSD) functions enabled. This feature will attach the destination number to the Call-through number. It does not require a data connection. You should however be aware that it only works in countries without fixed number lengths and if you have a trunk with your carrier that allows passing the additional digits.

12.16 Tracing

A support trace can be initiated on the *Status* page just like a factory reset. Please note that users should only use the trace service if asked to do so by their system administrator.

Figure 8: Open the *Trace Type* screen.

Depending on the issue that is observed with the AMC, the *Trace Type* should be narrowed down to:

- **Audio:** If the voice quality seems insufficient etc.
- **Call Setup:** Problems occur when a call is initiated.
- **Crash:** The AMC shuts down unexpectedly.
- **Network:** For registration issues etc.

The collected traces can then be forwarded by email.

Simple Logging

If there are issues with the Caller ID, use the option "Simple Logging". All logs regarding Caller ID transmission will then be saved to the file `iPhone_simple_log.txt`.

13 Manual download from the Aastra portal

On top of the automatic download of information from the Aastra portal that the AMC initiates it is also possible for you as a user to manually request download of information.

The options in the AMC menu are:

- Download configuration
- Download Feature file
- Download mobile LCR file

Download configuration downloads all the settings for the AMC and also the license for the application when it is created in the portal.

Download Feature file downloads the Feature file that is assigned for the user. There can be several Feature files on the portal but only one will be assigned to a specific user. The feature file provides the in- and out-call features that will be accessible from the AMC.

Download LCR downloads the LCR file. There can be several LCR files on the portal but only one will be assigned to a specific user. The LCR file provides information on how calls shall be routed for this user.

© 2012 Aastra Technologies Limited.
All rights reserved.

This document contains proprietary information, which is protected by copyright. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, or translated into another language, without the prior written consent of Aastra Technologies Limited.

NOTICE

The information in this document is subject to change without notice.

AASTRA MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Aastra shall not be liable for errors contained herein, neither for incidental nor for consequential damages in connection with the furnishing, performance, or use of these materials.

CE

AASTRA